

# Compatibility with Windows OS

8/30/2023

[Note]

- Please note that we have discontinued our support for any products not listed in these charts.
- We have tested new products with the latest versions as of August 2023.
- You can download the latest versions for free at <https://www.korg.com/us/support/download/>.

[Note for applications that have been released from KORGE and VOX]

- These are not compatible with Modern UI.
- These are not compatible with Windows 10 Universal Windows platform (UWP).

Product Name	OS	Windows 10 Version 22H2		Windows 11 Version 21H2	Windows 11 Version 22H2	Remarks
		(32-bit) Support	(64-bit) Support	(64-bit) Support	(64-bit) Support	
<b>Driver</b>						
KORG USB-MIDI Driver		under examination	under examination	Yes	Yes	
KORG BLE-MIDI Driver		under examination	under examination	under examination	under examination	
KORG 4ch Audio Driver		under examination	under examination	under examination	under examination	
KORG Basic Audio Driver		under examination	under examination	under examination	under examination	
<b>WORKSTATIONS AND SYNTHESIZERS</b>						
KRONOS/KRONOS X						
- Main Unit (USB-Audio/MIDI)		Yes	Yes	Yes	Yes*1	*1: Please use the input device properties under Settings>System>Sound with "Audio enhancements" set to Off.
- Editor		Yes*1	Yes*1	Yes*1	Yes*1	*1: If you are using Japanese on Windows 10/11, please use previous version of Microsoft IME.
- Plug-In Editor		Yes*2	Yes*1,2	Yes*1,2	Yes*1,2	*1: It does not work with 64bit DAWs. *2: If you are using Japanese on Windows 10/11, please use previous version of Microsoft IME.
NAUTILUS						
- Main Unit (USB-Audio/MIDI)		Yes	Yes	Yes	Yes*1	*1: Please use the input device properties under Settings>System>Sound with "Audio enhancements" set to Off.
- Editor		Unsupported	Yes*1	Unsupported	Unsupported	*1: If you are using Japanese on Windows 10, please use previous version of Microsoft IME.
- Plug-In Editor		Unsupported	Yes*1,2	Unsupported	Unsupported	*1: If you are using Japanese on Windows 10, please use previous version of Microsoft IME. *2: When using the Plug-In Editor for the first time, select "Open Settings." from the context menu of the Plug-In Editor and set the MIDI IN/OUT Port in the MIDI Setup.
KROME						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Editor		No*1	Yes	Yes	Yes	*1: Cannot install the editor.
- Plug-In Editor		No*2	Yes*1	Yes*1	Yes*1	*1: It does not work with 64bit DAWs. *2: Cannot install the plug-in editor.
KROME EX						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
KROSS						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Editor		No*1	Yes	Yes	Yes	*1: Cannot install the editor.
- Plug-In Editor		No*1	Yes	Yes	Yes	*1: Cannot install the plug-in editor.
KROSS 12						
- Main Unit (USB-Audio/MIDI)		Yes	Yes	Yes	Yes*1	*1: Please use the input device properties under Settings>System>Sound with "Audio enhancements" set to Off.
- Editor		No*1	Yes	Yes	Yes	*1: Cannot install the editor.
- Plug-In Editor		No*2	Yes	Yes	Yes	*1: It does not work with MOTU Digital Performer. *2: Cannot install the plug-in editor.
microKORG XL+						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Sound Editor		Yes*1	Yes*1	Yes*1	Yes*1	
microKORG						
- Sound Editor		Yes*1	Yes*1	Yes*1	Yes*1	*1: USB-MIDI Interface with the associated drivers installed.
KingKORG						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Librarian		Yes	Yes*1	Yes	Yes	
- KingKORG Updater		Yes	Yes	Yes	Yes	
wavestate						
- Main Unit (USB-MIDI)		under examination	under examination	Yes*1	under examination	*1: The KORG USB-MIDI Driver is not required or supported; the Windows class-compliant MIDI driver will be used automatically.
- wavestate/Editor/Librarian		under examination	under examination	Yes	under examination	
- wavestate/Sample Builder		under examination	under examination	Yes	under examination	
- wavestate/Updater		under examination	under examination	Yes	under examination	
wavestate SE						
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
- wavestate/Editor/Librarian		under examination	under examination	under examination	under examination	
- wavestate/Sample Builder		under examination	under examination	under examination	under examination	
- wavestate/Updater		under examination	under examination	under examination	under examination	
SV-1						
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
- SV-1 Editor		under examination	under examination	under examination	under examination	
SV-2						
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
- SV-2 Editor		under examination	under examination	under examination	under examination	
Grandstage						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
MS-20 mini / MS-20 Kit MS-20M Kit						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
ARP Odyssey						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
ARP ODYSSEY Module						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
ARP 2500 FS						
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
minilogue						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- minilogue/Sound Librarian		No	Yes	Yes	Yes	
- minilogue/System Updater		under examination	Yes	Yes	Yes	
minilogue xd						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- minilogue xd/Sound Librarian		under examination	Yes	Yes	Yes	
- minilogue xd/System Updater		under examination	Yes	Yes	Yes	
monologue						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- monologue/Sound Librarian		under examination	Yes	Yes	Yes	
- monologue/System Updater		under examination	Yes	Yes	Yes	
prologue						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- prologue/Sound Librarian		under examination	Yes	Yes	Yes	
- prologue/System Updater		under examination	Yes	Yes	Yes	
opsix						
- Main Unit (USB-MIDI)		under examination	under examination	Yes	under examination	*1: The KORG USB-MIDI Driver is not required or supported; the Windows class-compliant MIDI driver will be used automatically.
- opsix/Sound Librarian		under examination	Yes	Yes	Yes	
- opsix/Updater		under examination	under examination	Yes	under examination	
opsix SE						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- opsix/Sound Librarian		under examination	Yes	Yes	Yes	
- opsix/Updater		Unsupported	Unsupported	Unsupported	Unsupported	
modwave						
- Main Unit (USB-MIDI)		under examination	under examination	Yes*1	under examination	*1: The KORG USB-MIDI Driver is not required or supported; the Windows class-compliant MIDI driver will be used automatically.
- modwave/Editor/Librarian		under examination	under examination	Yes	under examination	
- modwave/Sample Builder		under examination	under examination	Yes	under examination	
- modwave/Updater		under examination	under examination	Yes	under examination	
NTS-1 digital kit						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- NTS-1 digital kit/Librarian		under examination	Yes	Yes	Yes	
- NTS-1 digital kit/System Updater		under examination	Yes	Yes	Yes	
NTS-2 oscilloscope kit						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
SQ-1						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
SQ-64						
- Main Unit (USB-MIDI)		under examination	Yes	Yes	Yes	
- KORG KONTROL Editor		No	Yes	Yes	Yes	
RK-100S						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Sound Editor		Yes*1	Yes*1	Yes*1	Yes*1	
RK-100S 2						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Sound Editor		Yes*1	Yes*1	Yes*1	Yes*1	
minKORG 700FS						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Librarian		Yes	Yes	Yes	Yes	
EK-50 Series						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
OS Series						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
<b>SOFTWARE SYNTHESIZERS</b>						
KORG Collection		No	Yes	Yes	Yes	
opsix native		No	Yes	Yes	Yes	
wavestate native		No	Yes	Yes	Yes	
modwave native		No	Yes	Yes	Yes	
KORG Gadget 2 Plugins for PC		No	Yes	Yes	Yes	
<b>Pianos/PSU/ACC</b>						
KHP-2000(KS-320)/KHP-5000(KS-520)/KHP-2500						
- Main Unit (Data storage)		Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
PaZPro						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa3X						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa300						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa500/588						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa600						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa700						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa800						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa900						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa1000						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
HAWIAN 30						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
MP10 Pro						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
Pa4X						
- Main Unit (Data storage)		under examination	under examination	under examination	under examination	
- Main Unit (USB-MIDI)		under examination	under examination	under examination	under examination	
G1G1 Air						
- Main Unit (Data storage)		Yes	Yes	Yes	Yes	
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
B2/B2SP/B2N						
- Main Unit (USB-Audio / MIDI)		Yes	Yes	Yes	Yes	
XE20/XE20SP						
- Main Unit (USB-Audio / MIDI)		Yes	Yes	Yes	Yes	
LP-380U						
- Main Unit (USB-Audio / MIDI)		Yes	Yes	Yes	Yes	
Llano						
- Main Unit (USB-Audio / MIDI)		Yes	Yes	Yes	Yes	
<b>CONTROLLERS</b>						
taktile						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Editor		Yes	Yes	Yes	Yes	
- taktile Updater		Yes	Yes	Yes	Yes	
TRITON taktile						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Editor		Yes	Yes	Yes	Yes	
- TRITON taktile Updater		Yes	Yes	Yes	Yes	
microKEY-25/76/1						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	
microKEY 2 37/49/61						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	
microKEY Air						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Main Unit (BLE-MIDI)		Yes	Yes	Yes*1,2	Yes*1,2	*1: Please install the latest version of KORG BLE-MIDI Driver for Windows. *2: Bluetooth 4.0 compatible system is required.
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	
nanoKEY Studio						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Main Unit (BLE-MIDI)		Yes	Yes	Yes*1,2	Yes*1,2	*1: Please install the latest version of KORG BLE-MIDI Driver for Windows. *2: Bluetooth 4.0 compatible system is required.
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	
- nanoKEY Studio Updater		Yes	Yes	Yes	Yes	
nanoKONTROL Studio						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Main Unit (BLE-MIDI)		Yes	Yes	Yes*1,2	Yes*1,2	*1: Please install the latest version of KORG BLE-MIDI Driver for Windows. *2: Bluetooth 4.0 compatible system is required.
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	
- nanoKONTROL Studio Updater		Yes	Yes	Yes	Yes	
nanoKONTROL 2						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- Editor Librarian		Yes	Yes	Yes	Yes	
nanoKEY 2						
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	
- KORG KONTROL Editor		Yes	Yes	Yes	Yes	