

# Compatibility with iOS

11/14/2023

**[Note]**

- Please note that we have discontinued our support for any products not listed in these charts.
- We have tested new products with the latest versions as of November 2023.

Product Name	OS	iPadOS 14 support	iOS 14 support	iPadOS 15 support	iOS 15 support	iPadOS 16 support	iOS 16 support	iPadOS 17 support	iOS 17 support	Remarks
<b>iOS Apps</b>										
KORG Gadget 2 for iOS		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG Gadget 2 Le for iOS		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module Pro		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG ELECTRIBE Wave		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iMono/Poly		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
ARP ODYSSEi		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iWAVESTATION		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iM1 for iPad		Yes	-	Yes	-	Yes	-	Yes	Yes	
KORG iPolysix for iPad		Yes	-	Yes	-	Yes	-	Yes	-	
KORG iMS-20 for iPad		Yes	-	Yes	-	Yes	-	Yes	-	
iKaossilator		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
iELECTRIBE for iPhone		-	Yes	-	Yes	-	Yes	-	Yes	
iELECTRIBE for iPad		Yes	-	Yes	-	Yes	-	Yes	-	
KORG iELECTRIBE Gorillaz Edition		Yes	-	Yes	-	Yes	-	Yes	-	
Bluetooth MIDI Connect		Yes	Yes	Yes	Yes	Yes	Yes	under examination	under examination	
<b>Computer Gear</b>										
Keystage-49/61										
- Main Unit (USB-MIDI)		No	No	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: USB-C to USB Adapter or Lightning to USB Camera Adapter is required. When connecting to an iPad/iPhone with a Lightning connector, you must connect an AC adapter (sold separately) to the DC 9V jack of the Keystage.
taktile										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	under examination	under examination	under examination	under examination	*1: Lightning - USB Camera Adapter is required. And you must update the taktile/TRITON taktile system to version 2.0, and boot it in low-power mode.
TRITON taktile										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	under examination	under examination	under examination	under examination	*1: Lightning - USB Camera Adapter is required. And you must update the taktile/TRITON taktile system to version 2.0, and boot it in low-power mode.
microKEY-25/37/61										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	under examination	under examination	under examination	under examination	*1: Lightning - USB Camera Adapter is required. microKEY-37/61 also require self-powered USB hub.
microKEY2-37/49/61										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
microKEY Air										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
- Main Unit (BLE-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Please update to the latest system.
padKONTROL										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	under examination	under examination	under examination	under examination	*1: Lightning - USB Camera Adapter is required. And AC adapter or self-powered USB hub is also required.
nanoKEY2										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
nanoKEY Studio										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1:Lightning - USB Camera Adapter and self-powered USB hub are required.
- Main Unit (BLE-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Please update to the latest system.
nanoPAD2										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
nanoKONTROL2										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
nanoKONTROL Studio										
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1:Lightning - USB Camera Adapter and self-powered USB hub are required.
- Main Unit (BLE-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes	Yes	under examination	under examination	*1: Please update to the latest system.

# Compatibility with iOS

11/14/2023

**[Note]**

- Please note that we have discontinued our support for any products not listed in these charts.
- We have tested new products with the latest versions as of November 2023.

Product Name	OS	iPadOS 14 support	iOS 14 support	iPadOS 15 support	iOS 15 support	iPadOS 16 support	iOS 16 support	iPadOS 17 support	iOS 17 support	Remarks
<b>Computer Gear</b>										
plugKEY										
- Main Unit (Audio/MIDI)		Yes	Yes	Yes	Yes	under examination	under examination	under examination	under examination	
<b>AUDIO</b>										
DS-DAC-10R										
- Main Unit (USB-Audio)		under examination	under examination	under examination	under examination	under examination	under examination	under examination	under examination	
<b>Mixer</b>										
MW-2408/1608										
- Main Unit (USB-Audio)		under examination	Yes*1	under examination	Yes	under examination	under examination	under examination	under examination	*1: Lightning - USB Camera Adapter is required.
<b>Amplifiers / Speakers</b>										
KORG KONNECT App		End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	
KONNECT Upgrade Tool App		End Of Support	End Of Support*1	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	End Of Support	*1: The display is equivalent to that of the iPhone.