

Compatibility with iOS

3/19/2025

[Note]

- Please note that we have discontinued our support for any products not listed in these charts.
- We have tested new products with the latest versions as of March 2025.
- An Apple USB-C to USB adapter or a Lightning to USB camera adapter is required to connect a MIDI controller product to an iPad or iPhone.

Product Name	OS	iPadOS 16 support	iOS 16 support	iPadOS 17 support	iOS 17 support	iPadOS 18 support	iOS 18 support	Remarks
--------------	----	-------------------	----------------	-------------------	----------------	-------------------	----------------	---------

iOS Apps								
KORG Gadget 3 for iOS		Yes	Yes	Yes	Yes	Yes	Yes	
KORG Gadget Le for iOS		Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module Pro		Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module		Yes	Yes	Yes	Yes	Yes	Yes	
KORG ELECTRIBE Wave		Yes	Yes	Yes	Yes	Yes	Yes	
KORG iMono/Poly		Yes	Yes	Yes	Yes	Yes	Yes	
ARP ODYSSEI		Yes	Yes	Yes	Yes	Yes	Yes	
KORG iWAVESTATION		Yes	Yes	Yes	Yes	Yes	Yes	
KORG iM1 for iPad		Yes	-	Yes	Yes	Yes	Yes	
KORG iPolysix for iPad		Yes	-	Yes	-	Yes	-	
KORG iMS-20 for iPad		Yes	-	Yes	-	Yes	-	
iKaossilator		Yes	Yes	Yes	Yes	Yes	Yes	
iELECTRIBE for iPhone		-	Yes	-	Yes	-	Yes	
iELECTRIBE for iPad		Yes	-	Yes	-	Yes	-	
KORG iELECTRIBE Gorillaz Edition		Yes	-	Yes	-	Yes	-	
Bluetooth MIDI Connect		Yes	Yes	Yes	Yes	Yes	Yes	

MIDI CONTROLLERS								
nanoKEY Fold								
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	
Keystage-49/61								
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: When connecting to an iPad/iPhone with a Lightning connector, you must connect an AC adapter (sold separately) to the DC 9V jack of the Keystage.
taktile								
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: self-powered USB hub are required.
TRITON taktile								
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: self-powered USB hub are required.
microKEY2-25/37/49/61								
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	
microKEY Air-25/37/49/61								
- Main Unit (USB-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	
- Main Unit (BLE-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	
nanoKEY Studio								
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: self-powered USB hub are required.
- Main Unit (BLE-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	
nanoKONTROL Studio								
- Main Unit (USB-MIDI)		Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: self-powered USB hub are required.
- Main Unit (BLE-MIDI)		Yes	Yes	Yes	Yes	Yes	Yes	

