

Compatibility with iOS

11/9/2018

Note: *Please note that we have discontinued our support for any products not listed in these charts.

We have tested new products with the latest versions as of Nov 2018.

Product Name	iPad iOS10 support	iPhone iOS10 support	iPad iOS11 support	iPhone iOS11 support	iPad iOS12 support	iPhone iOS12 support	
iOS Apps							
KORG Gadget for iOS	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Due to differences in screen size and CPU speed of iPhones, iPhone 5/5c/4S are not supported, only iPhone 6 or later is recommended.
KORG Gadget Le for iOS	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Due to differences in screen size and CPU speed of iPhones, iPhone 5/5c/4S are not supported, only iPhone 6 or later is recommended.
KORG Module	Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module Le	Yes	Yes	Yes	Yes	Yes	Yes	
KORG Module Standard for iPhone	-	Yes	-	Yes	-	Yes	*1: The display is equivalent to that of the iPhone.
KORG ELECTRIBE Wave	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iMono/Poly	Yes	Yes	Yes	Yes	Yes	Yes	
ARP ODYSSEi	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iWAVESTATION	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iDS-10	Yes	Yes	Yes	Yes	Yes	Yes	
KORG iM1 for iPad	Yes	-	Yes	-	Yes	-	
KORG iPolysix for iPad	Yes	-	Yes	-	Yes	-	
KORG iMS-20 for iPad	Yes	-	Yes	-	Yes	-	
iKaossilator	Yes	Yes	Yes	Yes	Yes	Yes	
iELECTRIBE for iPhone	-	Yes	-	Yes	-	Yes	*1: The display is equivalent to that of the iPhone.
iELECTRIBE for iPad	Yes	-	Yes	-	Yes	-	
KORG iELECTRIBE Gorillaz Edition	Yes	-	Yes	-	Yes	-	
AudioPocket for volca sample	-	Yes	-	Yes	-	Yes	
SyncKontrol for monotribe	-	Yes	-	Yes	-	Yes	
Lyrics for MIKU STOMP	-	Yes	-	Yes	-	Yes	
iAudioGate	Yes*1	Yes	Yes*1	Yes	Yes*1	Yes	*1: The display is equivalent to that of the iPhone.
cortosia (コルトシア)	-	Yes	-	Yes	-	Yes	
Step Master	-	Yes	-	Yes	-	Yes	
Bluetooth MIDI Connect	Yes	Yes	Yes	Yes	Yes	Yes	

Computer Gear							
taktile							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required. And you must update the taktile/TRITON taktile system to version 2.0, and boot it in low-power mode.
TRITON taktile							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required. And you must update the taktile/TRITON taktile system to version 2.0, and boot it in low-power mode.
microKEY-25/37/61							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required. microKEY-37/61 also require self-powered USB hub.
microKEY2-37/49/61							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required.
microKEY Air							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required.
- Main Unit (BLE-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
padKONTROL							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required. And AC adapter or self-powered USB hub is also required.
nanoKEY2							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required.
nanoKEY Studio							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter and self-powered USB hub are required.
- Main Unit (BLE-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
nanoPAD2							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required.
nanoKONTROL2							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: Lightning - USB Camera Adapter is required.

nanoKONTROL Studio							
- Main Unit (USB-MIDI)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1:Lightning - USB Camera Adapter and self-powered USB hub are required.
- Main Unit (BLE-MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
plugKEY							
- Main Unit (Audio/MIDI)	Yes	Yes	Yes	Yes	Yes	Yes	
AUDIO							
DS-DAC-10R							
- Main Unit (USB-Audio)	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	Yes*1	*1: You must use a compatible connection kit/adaptor made by Apple, and provide power from a USB hub that is equipped with a power supply.
Amplifiers / Speakers							
KONNECT App	Yes	Yes	Yes	Yes	Yes	Yes	
KONNECT Upgrade Tool App	Yes*1	Yes	Yes*1	Yes	Yes*1	Yes	*1: The display is equivalent to that of the iPhone.